

Installing The New Ball Joint Mount



1. remove the plastic thumb screw from the bracket on the LED module.



2. slide the ball joint mount into the bracket.



3. use a screw driver to tighten the screw on the bracket, it will fix the ball joint mount.



4. use the plastic thumb screw to fix the bracket on the LED module.