

Coralvue 4 and 6 Bulb T5/LED Fixture User Guide Instructions.

1. Keep fixture removed from power while setup and installing the lamps.

2. T5HO Lamps Installing:

1.1: Loosen Shield Lock-bracket at either side of Fixtures with phillips head screw driver.

1.2: Remove the acrylic shields on both sides of the LED center bracket

1.3: Insert T5HO lamps one by one and make sure to properly seat the lamps into the T5 sockets then turn the lamps to lock them into place and make electrical contact with the T5 bulb pins.

1.4: Insert the acrylic splash shields if you decide not to use the splash shields you do so at your own risk should the fixture get wet or corrosion builds on the wiring terminals inside the fixture.

1.5: Install the metal shield brackets back into place.

3. Leg mounting brackets Installation:

3.1: Measure the length and the thickness of the your tank

3.2 Start with one leg and align it with the two screws at the top of the fixture with the channeled slots on the T5 fixture (do not tighten the screws down at this point just get them started) now do the same to the other side of the fixture. With both legs now threaded tighten the 4 screws at top of Fixtures, adjusting the distance exactly same

size as your tank length.

3.3: Set the fixture on the tank and insure the proper spacing, make adjustments with the two screws holding each leg at this time.

3.4: Tighten the 2 black plastic screws at bottom of each leg bracket against the aquarium.

3.5: Mount or position the small electronic metal box where it will not get wet and is out of viewing sight.

3.6: Insert the 3 or 4 power plugs (depending on your model) into an electrical power strip. You can use timers for each power plug to control on/off times for every two T5 lamps and for the LED's

3.7: Switch on.

4. LED dimming control:

4.1: At the top of the fixture is a LED dimming control feature. By turning the dial it will allow you to adjust the intensity of the LED's. Corals and fish will span under moonlight and you may want to play with the intensity of LED's for moonlight effects. You can also run the LED's during the day time which will give corals a boost in glow do to the florescent colors of the super deep blue actinic LED's that used in these fixtures.

Troubleshooting Guidelines

T5 bulbs will not come on.

Make sure the T5 lamps are inserted properly and that you have the bulbs turned and locked into the sockets.

Make sure the power plugs for the T5 lamps are plugged into power.

Check the T5 bulb switches and make sure they are in the on position.

Remove the two screws on each side of the fixture that holds the acrylic shield brackets. This will allow you access to remove the LED bar and give you access to the T5 ballast. Check the T5 ballast for any loose wires that may have come off during shipping. If you see that a wire has come off one of the ballast slots push it back into place and it will lock the wire into the ballast. If you have any questions about this please call or email us with questions at support@coralvue.com or 985-781-9078 for technical help.

LED's will not come on.

Make sure the power plug for the LED's is plugged into power.

With power applied check the dimming knob located at the top of the fixture and turn it to the on position. You will hear it click when it is turned on or off.

Check the LED wiring by removing the two screws that hold the acrylic

shield brackets in place. This will allow you to remove the LED bar that holds all the LED's on it. Flip this bar over and check that all the wires are in place. If you see a loose wire that has come off one of the LED's push the wire connector back into place. If you are still having trouble or have any questions send us an email at support@coralvue.com or give us a call at 985-781-9078.